



SLATE LITE™



ECO|STONE™ Instructions for use

02.12.2016



PREPERATION

All sheets of *Slate-Lite* should be spread on a surface to check the vein of the material and be able to sort them to get a evenly distributed wall or floor application.



PROTECTION

To protect the natural stone surface apply the impregnator with a sponge roller in a very thin layer. Let the material dry for 30 minutes and the wipe off any access moisture to ensure no staining in the material surface. This can be done before and after application.

Slate-Lite Special Impregnator
Slate-Lite Special Protection

Sponge roller

ADHERING

Is is advisable to wear rubber gloves while working with *EcoStone*. *EcoStone* can be processed with white glues, glass fiber glass adhesives, spray adhesives and contact adhesives.

White glues
Glass fiber glass adhesives
Contact glues

Depending on the type of adhesive, the sheet, the wall or both should be glued. In the case of contact adhesives, the sheet hast to be put into the final position immediately, since no subsequent alterations are possible. Corrections can be made for other types of glue.

If required we can also assist in advising other possible adhesives.

If any adhesive has come out between the seems you can use the *Slate-Lite Special Cleaner* to rinse the same away.

After 48 hours you can put full pressure on the material.



CUTTING / DRILLING

The material can be cut with scissors or a carpet knife.

Carpet knife
Scissors

GROUTING

Usually it is recommend to process *EcoStone* seamless.



CORNERS

EcoStone can be bent around corners after heating (from 40°C).

Heat

In the approach *EcoStone* can also be deformed three-dimensionally.