



Acoustic panel ceiling


- 32 Acoustic panel ceiling
- 33 Panels for mounting with screws
- 45 General instructions
- 49 Panels for suspension in T-type profile frame ceilings
- 55 Ceiling solutions

CEWOOD panels with an extra mineral wool layer for the highest sound absorption

If CEWOOD Acoustic panels are fastened with extra mineral wool onto the outer building construction elements, a vapor barrier film must be laid under CEWOOD panels.

- Type and thickness of mineral wool shall be determined in the building project, in lie with the CEWOOD sound absorption test results. See pages 24-29.
- Ceiling frame element and suspension element distances must be reduced according to the ceiling load applied.


Metal CD profile frame



a. Single-layer metal frame

b. Metal frame


Wooden lath profile frame



a. Single-layer wooden lath frame

b. Wooden lath frame

T-type profile frame



Explanation of numbering

1. CEWOOD Acoustic panel
2. Mineral wool